

Warning:

Keep a distance at least 20 mm when folding,
To prevent pinching

Battery Notice

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Rechargeable batteries are only to be charged under adult supervision

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth. Do Not submerge in water.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.



MADE IN CHINA




MANUFACTURED FOR LADIDA BABY TOY CO.LTD

Add: East of Zhirui South Road, Qujiang Economic Development Zone,
Shaoguan, Guangdong Province, China.
Tel: 86-757-86294998 Fax: 86-757-86287066
Consumer Services: ladidaservice@gmail.com
www.babyhyb.com / www.ladidatoy.com

Pictures are for reference only, subject to in kind.



Enjoy Your Motherhood!



**Portable Baby Mobile
Instruction**


www.ladidatoy.com
www.babyhyb.com

Warning: Attach this toy out of the reach of the child. To prevent possible injury by entanglement, remove this toy when the child starts trying to get up on its hands and knees in a crawling position.




Warning:

- Always operate the toy away from eyes or face. Adult assembly required.
- Please read the following instructions and warnings carefully. Keep this instruction manual for future reference:
- Keep small parts away from Children.
- This product is suggested to be used from birth to 5 months.
- This crib mobile is intended for visual stimulation and is not intended to be grasped by the child.
- Always attached all provided fasteners (strings, straps, clamps, etc.) tightly to a crib or playpen according to the instructions.
- Do not add additional strings or straps to attach to a crib or playpen
- Keep out of the reach by children

Components:



Installation:



Operation:

